

LED UTILITY LIGHT FIXTURE MANUAL

PARTS INCLUDED




THIS DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY EXITS OR PORTABLE LUMINAIRES


OPTION A

SIMPLY SCREW INTO EXISTING LIGHT SOCKET

- 1** Remove mounting plate from fixture by turning plate counter-clockwise.



- 2** Remove cap to expose screw base. Note: Do not remove screw base cap if you're wiring the fixture to junction box.



- 3** Screw LED fixture into socket just like a light bulb.

